

 Carefully center end cap in tube making sure the cap is not cocked.

2. Use a soft faced hammer or rubber mallet and tap on the outer edge of the cap, moving around the edge in a circular movement. Make sure the cap does not cock! Continue tapping around until the cap is fully seated.

End Cap Installation Instructions