

# QUICK-FIX PRESTO PATCH™

UV LIGHT ACTIVATED FIBERGLASS REINFORCED  
SELF-ADHESIVE REPAIR PATCH



## PREMIUM REPAIR PATCH FOR TRUCK AND TRAILER REPAIRS

- Extremely durable fiberglass reinforced polyester/plastic
- Can be formed around grooves and corners
- Can be drilled, tapped, sanded or painted in less than an hour
- Will not rot or rust
- Resistant against many chemicals, solvents and oils
- Weather and UV resistant
- Temp resistant from -40°C to 200°C
- Bonds to all surfaces except polypropylene
- No shrinkage or expansion during the application or after curing
- Fast curing
- Available in 2"x3", 6"x9" and 9"x12" sizes

P/N	DESCRIPTION
982-00601	2x3 UV Light Activated Fiberglass Patch with Countertop Display, 48 individual patches
982-00601A	2x3 UV Light Activated Fiberglass Patch, 6 each
982-00602	6x9 UV Light Activated Fiberglass Patch, 12 each
982-00602A	6x9 UV Light Activated Fiberglass Patch, 2 each
982-00603	9x12 UV Light Activated Fiberglass Patch, 6 each
982-00603A	9x12 UV Light Activated Fiberglass Patch, 2 each
982-00600	UV Flashlight



**BEFORE:** Fix almost any hard surface in minutes.



**AFTER PATCH REPAIR:** Cures rock hard and resistant against many chemicals, solvents, and oils.

## APPLYING THE QUICK-FIX PRESTO PATCH™ IS EASY



**1.** Surface should be clean, dry and free of any contaminants. Cut patch into any size without exposing to UV/sunlight. Place remaining material back in foil protective bag.



**2.** Remove white backing tape to expose the sticky resin. Apply patch to repair area with sticky side down and press firmly to make sure the patch seals the entire area.



**3.** Remove the film backing on top side and expose to light. Curing time depends on UV intensity, between 5 - 50 minutes or use a UV light indoors with a minimum of 51 lumens.