## HOW TO INSTALL

# QUICK-FIX PRESTO PATCH™

The extremely durable Quick-Fix Presto Patch is designed to patch the holes, cracks, gaps, and tears commonly found on trucks & trailers. These instructions for installation are intended to be general guide to help the install.










### TOOLS NEEDED

- Gloves (optional)
- UV Light or Sunlight
- Scissors (optional)

1. Surface should be clean, dry and free of any contaminates. Cut patch into any size without exposing to UV/sunlight. Place remaining material back in foil protective bag.
2. Remove white backing tape to expose the sticky resin. Apply patch to repair area with sticky side down and press firmly to make sure the patch seals the entire area.
3. Remove the film backing on top side and expose to light. Curing time depends on UV intensity, between 5 - 50 minutes or use a UV light indoors with a minimum of 51 lumens.